

TOOLS033 Resetter HP Product Description



HP inkjet printer resetter can resetting following cartridge chip(HP10 / 11 /38/70/70L/ 12 / 13 / 82 / 84 / 85 / 88/88L):

1.HP10:

C4840A 26.5ML/C4844A 69ML/C4841A 28ML/C4843A 28ML/C4842A 28ML

2.HP11:

C4836A 28ML/C4837A 28ML/C4838A 28ML/C4836G 14ML/C4837G 14ML/C4838G 14ML

3.HP12:

C4804A 55ML/C4805A 55ML/C4806A 55ML

4.hp13

c4814a black 28 ml

c4815a cyan 14 ml

c4816a magenta 14 ml

c4817a yellow 14 ml

5.HP82:

C4911A 69ML/C4912A 69ML/C4913A 69ML

6.HP84:

C5016A 69ML/C5017A 69ML/C5018A 69ML

7 hp84

c5016a

c5017a

c5018a

8 hp85

c5016a

c5017a

c5018a

9. hp88

c9385a black 20.5 ml

c9386a cyan 9 ml

c9387a magenta 9 ml

c9388a yellow 9 ml

c9391a lc 17.1 ml

c9392a lm 17.1ml

c9393a ly 17.1 ml

c9394a lb 58.9 ml

Note: HP inkjet printer resetter can only reset compatible chips but not original chips. The original chips cannot be reset, but only replaced by compatible chips or ARC chips.

specifications The above chip model is suitable for compatible chips. HP inkjet printer resetter can reset only for compatible chips. It can not reset the original chips.

Advantages!

The methods of reducing the printing cost of HP printer:

1.If the ink in the original cartridge is used up,please change to: Compatible chip+HP chip resetter.

2.Refill cartridge+ARC chip

3.Refill cartridge+Compatible chip+HP chip resetter.

4.Used for HP Continuous Ink Supply System(CISS)

5.To use in HP Designjet Z2100 Cartridge:

1.LM(C9455)

2.LC(C9390)

3.PB(C9449)

4.LG(C9451)

5.MB(C9448)

6.C(C9452).

HP Photosmart Pro B9180:

1.PK(C9413)

2.LG(C9414)

3.MK(C9412)

4.C(C9415)

5.M(C9416)

6.Y(C9417)

7.LM(C9419)

8.(C9418).

The above four methods can reduce the printing cost effectively.Clients can choose one of them as per your favourite methods.